




vocas

Configuration chart Grass Valley LDX-C180

Version date: 14-7-25



Item Number	Description
0350-1410	Vocas Separate top handgrip (no rails)
0350-1455	Vocas 15 mm Viewfinder adapter
0350-1461	Vocas Microphone holder incl. shock absorber for 15 mm rails
0350-1495	Vocas VF holder for 15 mm LWS top rails
0350-2010	Vocas Clamping block for 15 mm rails
0350-2200	Vocas USBP-15 MKII
0350-2200-02	Vocas USBP-15 MKII with soft shoulder pad
0350-2220	Vocas Quick release dovetail plate
0350-2250	Vocas Camera adapter plate
0350-9105	Vocas Aluminum 15 mm rail, length: 105 mm (1 pc.)
0350-9210	Vocas Aluminum 15 mm rail, length: 210 mm (1 pc.)
0360-0525	Vocas 15 mm General lens support
0390-0010	Vocas Double sided handgrip extender short (66 mm)
0390-0020	Vocas Double sided handgrip extender medium (110 mm)
0390-0030	Vocas Offset Handgrip Extender long (150 mm)
0390-0040	Vocas Adjustable handgrip extender
0390-0104	Vocas perfect fit wooden handgrip (left hand)
0390-0105	Vocas perfect fit wooden handgrip (right hand)
0480-0021	Vocas BP-19 MKII with 295 mm long dovetail plate kit
0480-0500	Vocas 19 mm Universal lens support
0700-0011	Vocas Viewfinder bracket universal
0700-0031	Vocas Viewfinder bracket with rosette
0700-0056	Vocas NATO Clamp with 1/4" Pin-Lock for On-Camera Monitors
0710-1100	Vocas Single sided NATO rail with single 15 mm (100 mm)
0710-1170	Vocas Single sided NATO rail with single 15 mm (170 mm)
0710-1200	Vocas Single sided NATO rail with single 15 mm (200 mm)

