




Item No.	Part Number	Qty	Description
1	0350-3000	1	Flexible camera rig, FCR-15
2	0390-0045	1	Adjustable handgrip extender for Sony FX6
3	0390-0080	1	Body rosette adapter for Sony FX6