




Item	Part Number	Qt	Description
1	0350-2255	1	Camera adapter plate for Sony PXW-FS
2	11.250.05	1	USBP 15 MKII base plate
3	09.026.01	5	Spring 6,5x5,5xL10
4	09.016.03	5	Nut M4 for winged nut hexagonal
5	11.007.01	5	Ring 4,3x8x0,5 Din 433 St-Zn
6	04.037.01	5	Screw M4x25 din 965 A2
7	11.008.03	5	Winged nut hexagonal small
8	0350-2310	1	Shoulder pad standard
9	11.260.01	2	Magnet S-10-01-STIC
10	09.027.01	1	Hex. key 5mm. Unbrako DIN 911 kort
11	09.065.01	2	screw M6x25 DIN 912 A2-70
12	11.257.01	1	Clamping block 15mm USBP MKII
13	0350-9210	2	Pipe 210 mm. Sony Assy
14	11.258.01	3	Magnet CSN-13
15	09.204.01	3	Screw M2,5x8 DIN 965H ZnZ
16	11.259.01	1	spring 2.9x13 C93
17	11.253.01	1	Safety lock lid
18	744003	4	Screw M2X5 DIN965 4.8 ZN Z
19	11.254.01	1	Safety lock pin II
20	11.255.01	1	Safety lock slider
21	09.023.01	1	Screw M2,5x3 ISO1207 4.8 Zn
22	11.125.01	1	Pull bolt M8 III
23	746202	2	Spring 1.9x6.3 CS62
24	11.127.02	1	Lock lever M8 III
25	11.129.02	1	Dove tail lock plate
26	03.034.01	1	Alignment card AC-002