



# User manual Wooden handgrip right with LANC switch

Version 1.0.1



[www.vocas.com](http://www.vocas.com)

## Index:

Introduction .....	3
Guide to functions: .....	4
Attaching the cable: .....	5
Compatibility .....	6
Sony cameras .....	6
Canon cameras .....	6
Accessories .....	7
Additional information .....	8
Contact data: .....	8

# Introduction


Thank you for purchasing a Vocas product. You are now the owner of a revolutionary Wooden handgrip! More than 25 years of experience are part of the wooden handgrips design and functionality.

We believe that the Vocas Wooden Handgrip gives you the perfect configuration for your camera. You will now experience the combination of having your camera in perfect balance and operating your camera with a nice natural grip.

Before you start to use your new accessory, please read these instructions carefully to enjoy optimum performance and a longer service life. Keep this manual in a safe place for future reference.

In the interest of continually improving products, Vocas Systems B.V. reserves the right to update or modify information contained in this manual.

## Guide to functions:



### A: Start/stop button

This button allows you to start and stop recordings.

### B: Assignable button

You can assign different functions to this button. (See chapter 'Compatibility' for more information)

### C: Connector

3-pin connector to connect your remote cable (0390-0156)


### D: (Un)Lock knob

This red winged nut allows you to attach or remove the handgrip from a rosette.

## Attaching the cable:

When attaching the remote cable to the handgrip, make sure to align the two red dots (on the M/F connector).

**Please note:** Trying to force the cable into the connector any other way may damage the connectors.



# Compatibility

This handgrip only works on cameras with a 2.5 mm 3-conductor jack and a specific menu setting. Initially this product has been created for the Sony and Canon cameras. A complete list of today's popular compatible cameras is available on our website.

## Sony cameras

(PXW-FS5/7)


- Connect the plug into the LANC remote jack
- Press MENU
- System
- Assignable button
- Button 4




## Canon cameras

(EOS C100/300 MKII, EOS C500)

- Connect the plug into the LANC remote jack
- Press MENU
- Other functions
- Assignable buttons
- Button 4



# Accessories



Item No.	Part Number	Description
1	0390-0060	Rosette spacer 50 mm
2	0390-0104	Handgrip wood left exploded
3	0390-0110	Straight handgrip 15 mm rail bracket
4	0390-0106	Tilted handgrip 15 mm LW
5	0390-0111	Slidable handgrip 15 mm rail bracket
6	0390-0006	Handgrip combi rail bracket, for use on both 19 mm and 15 mm rails
7	0390-0015	Double sided handgrip extender 66 mm RED adapter
8	0390-0010	Double sided handgrip extender 66 mm
9	0390-0020	Double sided handgrip extender 110 mm
10	0390-0030	Offset handgrip extender 150 mm
11	0730-1170	Single sided NATO rail with rosette (170 mm)
12	0790-0001	NATO cable clip
13	0750-0003	NATO clamp horizontal rosette

**For all available accessories and compatibilities please check our website: [www.vocas.com](http://www.vocas.com)**

## Additional information

The Vocas wooden products are made of walnut and have been treated with a transparent mineral oil to increase the life expectancy. It is advised to repeat this treatment once in a while.

Using natural materials gives the Vocas handgrips their unique look and color. Every single handgrip has its own identity.

## Contact data:

Vocas Systems B.V.  
Larenseweg 121  
1221 CL Hilversum, The Netherlands  
T: +31(0)35-6233707  
[www.vocas.com](http://www.vocas.com)  
<https://www.facebook.com/vocassystems/>

